

PD-2600R Series Jumper Setting

RS-232 Format :

SW1		
1	2	RS232
ON	ON	9600 , E , 8 , 1
ON	OFF	9600 , N , 8 , 1(Default)
OFF	ON	19200 , E , 8 , 1
OFF	OFF	19200 , N , 8 , 1

Emulation Mode:

SW1			
3	4	5	Mode
ON	ON	ON	UTC
ON	ON	OFF	Aedex
ON	OFF	ON	Noritake(Default)
ON	OFF	OFF	Epson
OFF	ON	ON	Futaba
OFF	ON	OFF	ADM