

**PD-7600R Series Jumper Setting**

J2: Reserved

S3

	SW1	SW2	SW3
<b>EPSON Mode</b>	<b>OFF</b>	<b>OFF</b>	<b>OFF</b>
IEE 4Line *15 Mode	ON	OFF	OFF
IEE 2Line*15 Mode	OFF	ON	OFF
IEE 2Line*10 Mode (Center)	ON	ON	OFF
IEE 2Line*10 Mode (Align Text Right)	OFF	OFF	ON
IEE 2Line*10 Mode (Align Text Left)	ON	OFF	ON
Reserved	OFF	ON	ON
Reserved	ON	ON	ON

**SW4 : OFF ----- BIG5 Mode(Traditional Chinese)**

ON ----- GB Mode(Simplified Chinese)